




* PLEASE NOTE: Before beginning the installation, check that the parts contained in the carton and hardware package match those parts listed below. If you should find any discrepancies please contact Holcam Sales at 1-800-843-3332 www.holcam.com

WARNING

To avoid damaging the finish of this deluxe enclosure, use only mild cleaners. Always read the labels on the cleaner used. Do not use harsh chemicals or abrasive detergents.




HANDLE DETAIL


















CAT#:	PART LIST:	LENGTH:	QTY.:
1	DOOR ASSEMBLY		1
2	GLASS PANEL		2
3	H-3 STRIKE JAMB	68 7/16"	1
4	H-96 45° POST	68 3/4"	2
5	H-94 WALL JAMB	68 3/4"	2
6	H-95 JAMB INSERT	68 3/4"	2
7	H-55 HEADER /PANEL		2
8	H-55 HEADER /DOOR	C/L+1/2"	1
9	H-25 THRESHOLD /PANEL		2
10	H-25 THRESHOLD /DOOR	C/L+3/4"	1
11	H-99 FILLER		4
12	P-11 VINYL GUTTER		1
12A	GUTTER T-VINYL		1

HARDWARE PACK:	QTY.:
13 45° CORNER BRACKET	4
14 PLASTIC ANCHOR	8
15 10x2 PAN HEAD SCREW	8
16 6x3/8 PAN HEAD SCREW	24
17 6x3/4 PAN HEAD SCREW	10
18 VR-24 GUTTER PLUG	1
19 HANDLE	1
20 KNOB	1
21 HANDLE BOLT	1
22 NYLON WASHER	4
22 VINYL BUSHING	2



TOOLS REQUIRED FOR MODEL 5180 INSTALLATION

1. One tube approved bathroom sealant
2. Caulking gun
3. Hacksaw
4. Philips screwdriver
5. Mill file to smooth cut edges or radius
6. 1/8" drill bit for 6 x 3/8" screws
7. 1/4" drill bit for plastic anchors
8. 1/4" carbide drill bit for tile anchor installation
9. Rubber mallet

<p>1 Position door threshold #10 on centerline of sill. This part has been precut to match your stall.</p> 	<p>2 Measure distance from outside leading edge to back walls and cut #9 panel thresholds to fit. Attach thresholds together with #13 45° corner brackets and drill and attach with #16 6x3/8 pan head screws.</p> 	<p>3 Place one #5 wall jamb on #9 threshold. Plumb and mark screw holes. Drill with 1/4" drill bit and install plastic anchors.</p>  <p>NOTE: Execute steps 3 - 8 one side at a time.</p>
<p>4 Attach #5 wall jamb and #6 jamb insert through both parts. Tighten screws and back off about 3 turns to allow glass to slip between jambs.</p> 	<p>5 Place #2 panel on threshold #9. Measure distance between 45° corner post and wall jamb, then cut one #11 filler to that dimension.</p> 	<p>6 Set #2 side panel on edge of carpet or cardboard. Install #11 fillers on bottom of panel with rubber mallet, lubing edge of glass with soap or wax if necessary.</p> 
<p>7 Slide #2 panel into wall jamb until bottom filler is against wall jamb. Plumb panel and tighten screws to secure.</p> 	<p>8 Measure distance between wall jamb and 45° corner post at top of panel and cut and install one filler #11.</p> <p>REPEAT steps 3 thru 8 on opposite side.</p> 	<p>9 Place #8 door header on #4 45° corner posts and measure from outside edge of door header to wall and cut panel headers #7 to size.</p> 
<p>10 Assemble headers #7 and #8 with #13 45° corner brackets and #16 6x3/8" pan head screws.</p> 	<p>11 Attach headers at top of wall jambs and 45° posts using #17 6x3/4" pan head screws, on outside face at wall jambs and at inside at 45° posts.</p>  <p>Also put #17 6x3/4" pan head screws at thresholds, on the outside at both wall jambs and 45° posts.</p>	
<p>12 Slip #3 strike jamb into #4 45° post, then install door with hinge jamb into opposite post. Adjust door and magnetic strike to operate properly. Drill three 1/8" holes in each post, 6 total, through strike and hinge jambs and install with #16 6x3/8" screws.</p> 	<p>13 Cut vinyl gutter to a measurement of the door width dimension plus 5/8" to install. Gutter is notched at both ends so it can be used for left or right hand doors. Be sure to cut correct end.</p>  <p>Mount gutter on inside at bottom of door with sealant.</p>	<p>14 Assemble handle and knob through holes in glass with plastic bushing and washers.</p> 

We recommend filing any sharp corners that may cause injuries, then clean and run a continuous bead of sealant around the outside of the threshold and up the outside of the wall jambs.

NOTE: Do not caulk inside of the unit.