


## S-5 INLINE ENCLOSURE WITH MAGNETIC CATCH

\* PLEASE NOTE: Before beginning the installation, check that the parts contained in the carton and hardware package match those parts listed below. If you should find any discrepancies please contact Holcam Sales at 1-800-843-3332 www.holcam.com

**WARNING:**

To avoid damaging the finish of this deluxe enclosure, use only mild cleaners. Always read the labels on the cleaner used. Do not use harsh chemicals or abrasive detergents.





CAT#: PART LIST: LENGTH: QTY:

①	DOOR ASSEMBLY		1
②	PANEL ASSEMBLY		2
③	H-36 WALL JAMB	70 1/4"	2
④	H-55 HEADER		1
⑤	H-25 THRESHOLD		1
⑥	H-35 PANEL FILLER		4
⑦	H-18 STRIKE JAMB	70 9/16"	1
⑧	H-11 GUTTER		1
⑨	V-8 GUTTER VINYL		1

HARDWARE PACK: QTY:

⑩	10x2 PAN HEAD SCREW	6
⑪	8x1 PAN HEAD SCREW	4
⑫	8x3/4 FLAT HEAD SCREW	6
⑬	6x3/4 PAN HEAD SCREW	10
⑭	6x3/8 PAN HEAD SCREW	15
⑮	PLASTIC ANCHOR	6
⑯	GUTTER PLUG	1



**MODEL S-5  
WITH  
MAGNETIC  
STRIKE**

**TOOLS REQUIRED FOR INSTALLATION OF MODEL S-5 WITH MAGNETIC STRIKE:**

1. Caulking gun + approved silicone sealant
2. Rubber mallet
3. Hacksaw
4. Philips screwdriver
5. Mill file to smooth cut edges or radius
6. 1/8" drill bit for 6x screws
7. 9/64" drill bit for 8x screws
8. 5/32" drill bit for 10x2 screws
9. 1/4" drill bit for plastic anchors
10. 1/4" carbide drill bit for tile anchors

<p><b>1</b> Measure finished opening width at bottom of stall. Cut threshold to this dimension. Radius ends if stall has rounded corners (fiberglass).</p>	<p><b>2</b> Place wall jambs on threshold and plumb. Mark hole locations and drill 1/4" holes for plastic anchors. Secure jambs to wall with 10x2 screws.</p>	<p><b>3</b> Insert one panel assembly into hinge jamb of door assembly. Align top of panel to flush with top of door, then fasten with 8x3/4 flat head screws through hinge jamb.</p>
<p><b>4</b> Slide door/panel assembly from Step 3 into wall jamb for temporary positioning. Slide other panel assembly into other wall jamb, also temporarily.</p>	<p><b>5</b> Strike jamb is notched on both ends to facilitate right or left hand door installation.</p> <p>After determining which end will be top, trim bottom end even with notch.</p>	<p><b>6</b> Place strike jamb over panel. Adjust entire assembly to provide 1/8" to 1/4" clear gap between strike jamb and door. Adjust magnetic strike as necessary for proper operation.</p>
<p><b>7</b> Measure distance between wall jamb and hinge jamb. Cut bottom filler to size. Measure distance between strike jamb and other wall jamb, and cut other bottom filler to size. Remove door/panel assembly and install bottom fillers with 8x1 screws.</p>	<p><b>8</b> Re-install panel and door/panel assemblies over bottom fillers. Plumb and secure both panels to wall jambs with 6x3/8 screws inside and outside. Attach strike jamb to panel with 8x3/4 flat head screws.</p>	<p><b>9</b> Measure distance between top of hinge jamb and wall jamb, then cut filler to size and place over top of panel. Measure distance between strike jamb and wall jamb at other panel, cut and install other filler.</p>
<p><b>10</b> Measure distance from wall to wall at top of assembly and cut header to fit. Place header over jambs, top fillers, and strike, then fasten with 6x3/4 screws.</p>	<p><b>11</b> Locate and drill holes through threshold at wall jambs as illustrated. Secure threshold to wall jambs with one 6x3/4 screw at each end.</p>	<p><b>12</b> Install gutter over gutter vinyl at door bottom with 6x3/8 screws. Be sure gutter slopes down to hinge end, and vinyl extends to within 1/8" of threshold.</p>

NOTE: We recommend filing any sharp corners that may cause injury, then clean and run a continuous bead of sealant along the outside of threshold and up wall jambs. Do not caulk inside of the unit. Polarity of the magnet may be reversed. To change polarity, remove magnetic strip from strike jamb, turn end for end, and re-install.