


*** PLEASE NOTE:** Before beginning installation, check that parts contained in the carton and hardware package match those parts listed below. If you should find any discrepancies please contact Holcam Sales at 1-800-843-3332



WARNING
TO AVOID DAMAGING THE FINISH OF THIS DELUXE ENCLOSURE, USE ONLY MILD CLEANERS. ALWAYS READ THE LABEL ON THE CLEANER USED. DO NOT USE HARSH CHEMICALS OR ABRASIVE DETERGENTS

PARTS LIST

ITEM	NAME	QTY	PART #
1.	Threshold	2	H-200
2.	Wall Jamb	1	H-12
3.	Wall Jamb	1	H-36
4.	Filler	1	H-36
4A.	Filler	2	H-58
5.	End Panel	1	
6.	Corner Post	1	H-24
7.	Corner Jamb	1	H-41
8.	Header	2	H-15
9.	Glass Panels	2	
10.	Towel Bars	2	H-75

HARDWARE PACK


11.	10 X 2" Flat Head Screw	3
12.	Bumpers	6
13.	10 x 3/4" Flat Head Screw	3
14.	Hanger Bracket	4
15.	8-32 x 3/8" Machine Screw	4
16.	Lock Washers	4
17.	Rollers	4
18.	8 x 5/8" Flat Head Screw	2
19.	Handle	1
20.	6 x 3/8" Pan Head Screw	30
21.	Angle Bracket	2
22.	Panel Guide	1
23.	8 x 1" Pan Head Screw	3
24.	Plastic Anchors	6
25.	Jamb Guide	2
26.	Towel Bar Brackets	2
27.	8/32 x 7/16" Machine Screw	4
28.	10 x 2" Pan Head Screw	3

INSTALLATION INSTRUCTIONS MODEL AT-14

1. A. Measure the centerline of sill for end panel and add 1" to this measurement. Cut end threshold #1A to this size.


B. Position end threshold on centerline of sill, measure from corner of end threshold to wall, subtract 5/16" and cut door side threshold.

C. Assemble thresholds with angle bracket. Drill 1/8" holes through threshold and bracket, secure with #6 x 3/8" pan head screws.




2. Place wall jamb #2 down over end of threshold, plumb and mark hole locations. Drill 1/4" holes. Insert plastic anchors and secure jamb to wall with #10 x 2" flat head screws through bumpers.

***NOTE:** On some tubs and showers it may be necessary to file corner of wall jamb and track to match the radius of the sill.




3. Measure from wall to inside corner of threshold. Cut filler #4A to size and set into place as shown. Position #3 wall jamb on threshold, plumb and mark hole locations.



Drill 1/4" holes. Insert plastic anchors and secure jamb to wall with #11-10 x 2" flat head screws.





4. Assemble #6 corner post and #7 wall jamb, hold in place at corner of threshold. Measure distance between wall jamb and corner post. Cut filler #4 to size. Position filler on threshold and drill 1/8" holes through bottom of filler and into threshold. Secure filler to threshold with #6 x 3/8" pan head screws.




5. Install panel into wall jamb and bottom filler. Install corner post and plumb the panel and corner post. Drill 1/8" holes through wall jamb and panel, secure with 6 x 3/8" screws. Plumb corner post and drill 1/8" holes through post and panel and secure with 6 x 3/8" screws. Install H-41 jamb in corner post. Drill 1/8" holes through corner post and jamb, secure jamb to post with 6 x 3/8" screws. Install # 4A filler in-between corner post and lip of track and H-41 corner jamb.





6. Measure from wall to corner of post, add 5/8" to this measurement and cut header to length. Place header in position on top of wall jamb and corner post. Measure from corner of panel header to wall on door side, cut header to this dimension.




7. Remove headers and assemble with angle bracket and 6 x 3/8" screws. Position header to match tightly at mitered corner. Lay splice plate on top and drill 1/8" through splice plate and header. Secure header and splice with 6 x 3/8" screws.




8. Install header assembly. Drill 9/64" holes through header and jambs. Secure header to jambs with 8 x 1" pan head screws. Drill and secure at corner post also. Install bumpers on H-41 corner jamb, use spacing of bumpers on opposite wall jamb as a guide, drill 1/8" holes and secure with 8 x 3/4" flat head screws.




9. Assemble door panels. See end view for location and position of brackets and rollers.




Slide hanger bracket into channel on top of panel, position bracket even with side rail. Crimp channel down to hold bracket in place.



Install rollers on hanger brackets as illustrated. Center roller on bracket and secure with 8/32x3/8" pan head screw and lockwasher.




Adjustment to bring door panels flush with wall jambs may be made by moving rollers in the diagonal slot in hanger bracket




END VIEW


10. Slide # 22 guide to center of track under panels. Drill 1/8" hole through panel guide and track. Secure guide to track with one # 10-6x3/8" pan head screw.




11. Install one # 26 towel bar bracket on outside panel with two 8/32x7/16" flathead screws. Insert both # 10 towel bars and install second towel bar bracket



12. Install handle on inside panel with two # 27-6x5/8" flathead screws. Hang and adjust panels from inside of tub. Hang outside panel, then hang inside panel.



Install # 25 jamb guide by removing tape backing and then attaching at lower inside leg of wall jamb as shown.



TOP VIEW

SEALING INSTRUCTIONS

We recommend filling any sharp corners that could cause injury. Clean unit thoroughly and run a continuous bead of silicone on outside leading edge of unit. Also seal where wall jamb and track meet. Do not seal inside edge of unit to allow for drainage. Allow sealant to cure for 24 hours before using shower.