


*** PLEASE NOTE:** Before beginning installation, check that parts contained in the carton and hardware package match those parts listed below. If you should find any discrepancies please contact Holcam Sales.

1-800-843-3332
www.Holcam.com
Holcam@worldnet.att.net



*** WARNING***
TO AVOID DAMAGING THE FINISH OF THIS DELUXE ENCLOSURE, USE ONLY MILD CLEANERS. ALWAYS READ THE LABEL ON THE CLEANER TO BE USED. DO NOT USE HARSH CHEMICALS OR ABRASIVE DETERGENTS

PARTS LIST

ITEM	NAME	QTY	PART #
1.	Glass Door Panel	2	
2.	Glass Step Panel	1	
3.	Wall Jamb	1	H-12
4.	Threshold	1	H-200
5.	Header	1	H-15
6.	Panel Wall Jamb	1	H-36
7.	Transition Wall Jamb	1	H-41
8.	Transition Filler	1	H-35
9.	Step Panel Bottom Channel	1	H-36
10.	Towel Bar	2	H-75



Towel Bars

HARDWARE PACK


11.	#10 x 3/4" Flat Head Screw	2
12.	Bumper	6
13.	Hanger Brackets	4
14.	#8-32 x 3/8" Truss Head Screw	4
15.	Lock Washer	4
16.	Roller	4
17.	#10 x 2" Flat Head Screw	4
18.	#8 x 1" Pan Head Screw	2
19.	#6 x 3/8" Pan head Screw	18
20.	Panel Guide	1
21.	#6 x 5/8" Flat Head Screw	2
22.	Female Handle	1
23.	Jamb Guide	2
24.	Towel Bar Bracket	2
25.	#8 x 7/16" Machine Screw	4
26.	#10 x 2" Pan Head Screw	3
27.	#6 x 3/4" Pan Head Screw	1
28.	Plastic Anchor	7

INSTALLATION INSTRUCTIONS MODEL AT-14 INLINE TUB ENCLOSURE


1. Measure centerline of sill. Cut #4 threshold 3/8" less than measurement. Position threshold with slope towards the inside of the stall. Note: It may be necessary to radius threshold and wall jamb to match radius of stall.




2. Place wall jamb # 3 down over end of threshold, plumb and mark hole locations. Drill 1/4" holes. Insert plastic anchors and secure jamb to wall with #10x2" flat head screws through bumpers.




3. Place transition wall jamb #7 down over end of threshold. Plumb jamb and mark hole location on stub wall. Remove jamb. Drill 1/4" hole and insert plastic anchor. Reinstall wall jamb and secure to stub wall with #10x2" flat head screw through bumper




4. Align #6, panel wall jamb with channel of transition wall jamb. Plumb panel wall jamb and mark hole locations. Drill 1/4" holes and insert plastic anchors. Secure jamb to wall with #10x2" pan head screws.




5. Measure distance between panel wall jamb and transition jamb. Cut the step panel bottom channel to size. **Drill two or more drain holes along inside bottom edge of the bottom channel.** Place channel in-between jambs and mark hole locations. Drill 1/8" holes. Put a dab of silicone in holes and secure channel with #8x1" pan head screws.




6. Loosen screw holding transition jamb to stub wall. Install step panel in wall jamb and bottom channel. Position transition jamb over edge of panel and tighten screw in stub wall. Plumb panel to achieve even reveal in jambs. Drill 1/8" holes through jambs and panel. Secure panel to jambs with #6x3/8" pan head screws.




7. Measure wall to wall at top of unit. Cut the header 1/16" less than measurement. Install header over the top of wall jambs. Secure header to jambs at location A & B with # 6x3/8" pan head screws. Secure header at location C with # 6x3/4" pan head screw.




8. Assemble door panels. See end view for location and position of brackets and rollers.




Slide hanger bracket into channel on top of panel, position bracket even with side rail. Crimp channel down to hold bracket in place.



Install rollers on hanger brackets as illustrated. Center roller on bracket and secure with 8/32x3/8" truss head screw and lockwasher.




Adjustment to bring door panels flush with wall jambs may be made by moving rollers in the diagonal slot in hanger bracket




END VIEW


9. Slide # 20 guide to center of track under panels. Drill 1/8" hole through panel guide and track. Secure guide to track with one #19-6x3/8" pan head screw.




10. Install one # 24 towel bar bracket on outside panel with two 8/32x7/16" flat head screws. Insert both # 10 towel bars and install second towel bar bracket




11. Install handle on inside panel with two # 21-6x5/8" flathead screws. Hang and adjust panels from inside of tub. Hang outside panel, then hang inside panel.



Install # 23 jamb guide by removing tape backing and then attaching at lower inside leg of wall jamb as shown.



TOP VIEW



SEALING INSTRUCTIONS

We recommend filing any sharp corners that could cause injury. Clean unit thoroughly and run a continuous bead of silicone on outside leading edge of unit. Also seal where wall jamb and track meet. Do not seal inside edge of unit to allow for drainage. Allow sealant to cure for 24 hours before using shower.